

---

## CTS Battery Holder

---

Variant	positions
CTS-H-3	AA (2*) AAA (2*) Button cells (2*) <b>Only one type of cell per channel must be plugged in at the same time!</b>
CTS-H-AA	AA (2*) with temperature sensor
CTS- H-AAA	AAA (2*) with temperature sensor
CTS- H-C	C (2*) with temperature sensor
CTS- H-SC	Sub-C (2*) with temperature sensor
CTS- H-D	D (2*) with temperature sensor

Max. current: 2A